

Solar Audio Player Papyrus

Renew
Reaching the Remote



- 1 Power Button
- 2 Power Light
- 3 Battery Lights
- 4 Volume Up/Down
- 5 Audio Source
- 6 Play/Pause
- 7 Next Song
- 8 Previous Song
- 9 Next Album
- 10 Previous Album



11 AC Power Input

12 SD Card Slot

13 USB Input

14 Headphone Output

ATTENTION! Hold power button 4 full seconds to turn ON



Running the Player...



(hold **4 seconds**)

Insert SD Card **ONLY**
when player is ON
(Card may be left in
player between uses)



...from SD Card



(green power light)



Push to switch between
memory sources

...from Internal



(red power light)



Charging the Battery...


...using AC power



...using the sun



If lights remain lit or
flicker, sun charge is
too weak



...using computer



To test battery, press power button
1 second. 4 lights = full, 1 light = empty

