

CHARGING THE BATTERY...

...using the sun



Face solar panel towards sun 1 full day.

...using AC power



Plug into wall overnight.

RUNNING THE PLAYER...


...from the battery



...from AC power



EXTERNAL AMP/SPEAKER



PLAYING A MOVIE

Return button selects the raised icon



ON-UNIT CONTROLS

...in Menu

Up


Down

Left

Right

Select

Menu



...in Movie

Volume Up

Volume Down

Skip Back

Skip Forward

Play/Pause

On-Screen Display

Menu



Skip Back

Rewind

Play / Pause

Fast Forward

Skip Forward

Stop

Zoom

AFTER USING...

... turn off the speaker and the RAN 10 Screen



PARTS LIST

- 1 10" RAN Screen
- 2 1 Carrying Case
- 3 Solar Panel
- 4 Rechargeable Battery
- 5 Remote Control
- 6 AC Power Cable
- 7 Battery to RAN Cable
- 8 External Speaker/Amp
- 9 RAN to Speaker Cable

